
... continue with the middle strands which you tighten diagonically, ...







Back view of the tilted ringsling.

Imprint

Ringsling: GIRASOL, Eisenacher Strasse 71, D - 10823 Berlin Phone: +49-30-7811584, Email: info@girasol.de, www.girasol.de Concept: Madame Jordan / madamejordan.de

Design: www.berliner-trageberatung.de

Photos: Maria Herzog

... till you reach the lower rail which you pull straight downwards. In the end this rail runs almost horizontally between you and your baby. Advice: Lift your baby every time you pull the sling. Thus the rings move less. And it is easier to pull!




... lift the wrap over your child's head.

Care

- Pre-washed.
- Machine wash (30°C/86°F up to 60°C/140°F) in a washing net or pillow case with mild detergent on gentle cycle. Please do not bleach or tumble dry.
- Please check all seams after washing.

To take the baby out of the ringsling you support your baby's bum with one hand. With your other hand you lift the upper one of the rings and loosen the sling a

little bit.







Done!

Additional information and recommendation

The ringsling

- is an ideal carrier for children from newborns, even preemies, to toddlers (up to 3,5 years old). Recommended weight: From 7 to 35 lbs.
- can be used for front or hip carry. Experienced babywearers use the ringsling even for the back carry.
- should not be in the crook of your neck, but spread evenly over your shoulder and reach to your upper arm to spread the weight better. Be sure your baby is at or above your waistline.
- is easy to put on and take off. After taking your baby out of the ringsling, the wrap remains in the rings. You only have to arrange the folds in the rings a little bit. Thus, it is instantly ready for use.
- made from a soft wrap might give way a little after a while, so that you have to re-tighten it now and again. In this case, washing the ringsling might help.
- allows for discreet breast-feeding. Just loosen the ringsling a little and bring your baby in the right position. You can use the tail of the ringsling for a great privacy cover. Afterwards, do not forget to tighten the ringsling again.
- can be used without the tilting on your back. However, the tilted variation gives you a tighter upper rail, improves your baby's position in the ringsling and helps to bring her legs level. On the whole, the tilted variation is more comfortable for baby and cargiver.

SUFFOCATION HAZARD

- Ensure the infant's face is above the fabric, visible, and free from obstruction at all times.
- Babies at greatest risk of suffocation include those born prematurely, those with respiratory problems and those under four months of age. •Ensure the baby does not curl into a "C" position with the chest resting on or near the chest. This position can interfere with breathing, even if nothing is covering the nose or mouth.

FALL HAZARD

- Leaning, bending over, or tripping can cause baby to fall. Keep one hand on baby while moving.
- Follow the manufacturer's recommended weight range when using this carrier. Never use the carrier for a preterm infant without seeking the advice of a healthcare professional.

WARNINGS

- Please read these instructions and warnings carefully before use.
- Keep this manual for future use.
- · Always check your ringsling for wear or damage before use.
- Ensure that the baby is safely positioned in the ringsling according to manufacturer's instructions for use.
- Never leave a baby in a ringsling that is not being worn.
- Check on the baby often. Ensure the baby is periodically repositioned.
- If using the ringsling while breast-feeding, always move the baby's face away from the breast after the baby is done feeding.
- Never wear your baby when balance or mobility is impaired because of exercise, drowsiness, or medical conditions.
- Your balance may be adversely affected by your movement and that of your baby.
- Never place more than one baby in the ringsling. Never use/wear more than one ringsling at a time.
- Never use the ringsling while engaging in activities such as cooking and cleaning which involve a heat source or exposure to chemicals.
- Never wear your baby while driving or being a passenger in a motor vehicle or in an airplane.
- This ringsling is not suitable for use during sporting activities.

The GIRASOL **Babysling**



Ringsling Instruction Manual



Ringsling **Instruction Manual Vertical position**

Put the rings on your shoulder.

(







Keep hold of the upper rail... ... and gather the fabric together.

Reach under the sling behind your back, grab the lower rail from under the sling and pull it to the front. The sling on your back is now tilted: the lower rail is



Thread the gathered tail

through both rings from

... and through the lower ring back down. The upper ring is now covered.





Spread out the fabric evenly Done threading! in the lower ring, avoid twisting. Each edge passes through the rings and out clearly, so that they are at the far end in the rings.



Put the rings on your shoulder. The sling's loop should be roughly waist-high.






Hold your child with one hand. With your free hand slip inside the sling, grab the find the upper rail of the baby's legs and lead them into the loop. Let your baby glide into the pouch part of the sling. The baby is "sitting" on the lower part of the loop now.

Take your baby up and put her at the uncovered shoulder above the loop. A younger baby may rest his head at your shoulder, an older one can sit a little higher.








Reach from the bottom between your baby's legs and grab the lower rail.






Pull the sling under baby's









Now you tighten the whole tail strand by strand. To prevent the rings from wandering across your chest, follow the way the wrap takes: start with the upper rail and pull it horizontally, ...